

Daljinski upravljač Philips

RC8205

Za robnu marku: Philips

RTV: RC820500

NJK: 1207

MJK: 1207

PTK:

Kompatibilan sa originalnim oznakama DU:

310420702781
31191086457
31191086459
312814710611
312814711381
313914852152
313914852701
313914854291
313914854321
391014852561
482221821044
482221821093
482221821116
482221821117
482221821145
482221821148
482221821212
482221821274
482221821285
482221910213
482221910287
482221910289
482221910464
482221910469

RC020500
RC030200
RC031000
RC0311
RC076101
RC076401
RC5931
RC6312
RC6803
RC7823
RC8201
RC820100
RC820500
RC820501
RC820520
RC8207
RC821101
RC8213
RC8215
RC821501
RC8251
RC9032
RC9051
RC9055
RC9057
RC9065
RC9067
RC9070



RC9071
RC9073
RC9076
RC9133
SBCRP520
SBC3619

Za sledeće modele televizora:

14AA3527
14GR1227GOYA
14GR122742L
14PT118A
14PT132A
14PT1322
14PT133200
14PT134220
14PT135AVERON.
14PT135200
14PT135300
14PT135320
14PT136AVERON.
14PT136B00DEGAS
14PT1363S
14PT1363X
14PT1363Z
14PT136300
14PT136311
14PT137201G
14PT137311S
14PT138A
14PT153200B
14PT154200
14PT155A
14PT155B
14PT1552
14PT1553
14PT156A
14PT156B00
14PT156200
14PT156300
14PT156311
14PT157311
14PT1574V
14PT1574Y
14PT157400B
14PT157400G
14PT157400S
14PT157400Y
14PT157400Z
14PT266300
15AA3537
15AB3536CARRA
15PT121A
15PT136B
15PT156B
15PT161A
153933PP
17AA3547
17HT315241
17PT136B
17PT156B00
17PT156311
17PT161A
17PT166AMATISSE
17PT166B
174933PP
20PT118A
20PT132A
20PT1352

20PT1353
20PT138A
20PT1552
20PT155300
21315B
21AA335620B
21AB355600B
21PT131A
21PT134BGIOTTO
21PT1342
21PT135B00
21PT135300
21PT136A
21PT136B
21PT161A
21PT161B
21PT164ACHAG.
21PT164B00CHAG.
21PT165B
21PT165300
21PT166B00
21PT166300
21PT166311
21PT4103
21PT4303
21PT440300
21PT440400
21TCDI3000
215433PQ
215933PP
25DC206540RMATCHL.
25DC2660DIGITAL
25PT4001
25PT4051
25PT410300
25PT410358
25PT415100
25PT440300
25PT445400
28DC207540R
28DC2670DIGITAL
28PT400100
28PT400101
28PT4051
28PT4101
28PT410300
28PT415100
28PT440300
28PT440400
28PT440420
28PT440430
28PT440601
28PT445300
28PT445400
28PT465400
32PW955612
32PW955612R
37KV121202B
37TA1040
37TA1161
37TA1171
37TA1210
37TA1232
37TA124208
37TA1273
37TA1432
37TA1471
37TA1473
37TA232
37TB1141

37TB1190
38ZY3325
38ZZ3383
38ZZ3385
43ZY3425
43ZZ3483
43ZZ3485
51TA1460
51TA147216
51TA1473
52TA1471
52TA147218
52TA4315
52ZY3535
52ZY3593
52ZZ3583
63KD2626
63TA3913
63TA4413
63TB3893
70KD2726VIDEOLINE
70TA3913
70TA4413
70TB3893
AA332714"
AA352714"
DC2660
DC2670DIGITAL
GR1227
L20135B
L20155B
L21135B
L21165B
P14135B
P14155B
P15136B
P15156B
P17136B
P17156B
VL14136A
VL14136B
VL21136B