

Daljinski upravljač Sony

RC-S0887

Za robnu marku:
PROSONIC

RTV:
NJK: 1206
MJK: 170
PTK: P832

Upotrebljiv za modele:
SASIJAPT90,PT92,PT100

PhilipsPHONOLAIPNSI37M12
PhilipsSWINGPHONOLA

Kompatibilan sa originalnim oznakama DU:

Alba313010821341
AlbaS313010821341
AlbaS31301082143
Aristona313010821191
Aristona313010821341
Caryonse313010821191
Caryonse313010821341
Combitech313010821191
Erres313010821191
Erres313010821341
Horizont313010821191
Horizont313010821341
Kriesler313010821191
Kriesler313010821341
Magavox313010821191
Magavox313010821341
McMichael313010821191
McMichael313010821341
Orion313010821191
Philips313010821191
Philips313010821341
PhilipsRC21191
PhilipsRC2143
PhilipsSF10
Phonola313010821191
Phonola313010821341
Procyon313010821191
Procyon313010821341
PYE313010821191
PYE313010821341
Radiola313010821191
Radiola313010821341
Saville313010821191
SBR313010821191
SBR313010821341
Schneider313010821191
Sei313010821191
Sei313010821341
Siera313010821341
Simatec313010821191
Sinudyne313010821191
Sinudyne313010821341
...

