

Daljinski upravljač Toshiba

CT9430

Za robnu marku: TOSHIBA

RTV :CT9430

NJK: 1077

MJK: 337

PTK: P3033

Upotrebljiv za modele:

1400RB
1400RD
1400RN
1400RT
1400TB
1413XSV
1440RD
1440RT
1440VT
1450TMJ
147T9M
1510RD
1510TB
155R9BG
155R9BT
155R9BW
155R9BZ
156R9BG
156R9BT
156R9BW
160F5W
163F5DZ
163F5WZ
1720RT
1720TT
1722TB
1730TD
1732TD
175R9T17"
2013XS
2013XSE
2013XSV
2031TM
2035TM
207T9M
21R01F
2100RBT
2100RF
2100TBT
2100TD
2100TS
2100TTT
2101TBT
2102RT
2102TBT
2103BT
2104TLA
2104TM
2104XHV
2104XM
2104XMJ
2104XS
2104XS1
211T4TA
2112DD21"



2112DTT21"
212S4W
212T4W
2120HC
2120QS
2120RCV
2120XM
2121D
2121RD
2125XM
2125XMJ
2125XSR
2132DD
2132DN
2132TS
2135XSR
2137DD
214R21"
2140RF
2140RT
2140TD
2140TT
2141R
2141TT
2145DD
2150TD
2151DB
2151DD
2151RF
2155DD
216R9D
216R9F
216R9T
217D9T
217S9F
218D9D
218D9T
218Q6S
219D5C
219T
219X6M
221F3T22"
222T5B22"
2500SFT
2500TD
2500TT
2512DD25"
2535DD
2535DT
2537DD
2545DD
2552DD
2552DT
261F3T26"
261S3W
261S3WD
28D8D
2800RF
2800TD
2812DD
2812DTT
2832TF
2835DD
2835DT
2836DF
2837DD
284T9D
289S8A
515XS1
7010HYP

7030DD
7037DD
FTZ22632SK
TM2013
TV1400RT
TV1720RT
TV1720TT
TV219X6M
TV2857DD
TV3357DD
TVC29PROGR.TELETEXT
...

Kompatibilan sa originalnim oznakama DU:

11SYSTEM
23120005
23120092
23120093
23120272
23120292
23120348
23120357
23120358
23120361
23120362
23120368
23120387
23120474
23120476
23120478
23120490
23120493
23120494
23120495
23120496
23120521
23120532
23120533
23120576
23120578
23120582
23120595
23120605
23120673
23120743
23120764
23120771
23120852
23306004
23306005
CT9076
CT91
CT9133
CT9134
CT9140
CT9159
CT9199
CT9290
CT9292
CT9293
CT9294
CT9298
CT9356
CT9357
CT9369
CT9374
CT9379
CT938
CT9381

CT9383
CT9384
CT9385
CT9386
CT9387
CT9396
CT9399
CT9400
CT941
CT9414
CT9430
CT9432
CT9450
CT9455
CT9462
CT9463
CT9465
CT9475
CT9476
CT9480
CT9481
CT9507
CT9526
CT9552
CT9580
CT9581
CT9616
CT9617
CT9640
CT9737
CT983
CT9949
ALKOSCT9430
HISHITOCT9430
JECCT9430
...