

## Daljinski upravljač Prosonic

### RC-832

Za robnu marku:  
PROSONIC

RTV:  
NJK: 1206  
MJK: 170  
PTK: P832

Upotrebljiv za modele:  
SASIJAPT90,PT92,PT100

PhilipsPHONOLAI PNSI37M12  
PhilipsSWINGPHONOLA

Kompatibilan sa originalnim oznakama DU:

Alba313010821341  
AlbaS313010821341  
AlbaS31301082143  
Aristona313010821191  
Aristona313010821341  
Caryonse313010821191  
Caryonse313010821341  
Combitech313010821191  
Erres313010821191  
Erres313010821341  
Horizont313010821191  
Horizont313010821341  
Kriesler313010821191  
Kriesler313010821341  
Magavox313010821191  
Magavox313010821341  
McMichael313010821191  
McMichael313010821341  
Orion313010821191  
Philips313010821191  
Philips313010821341  
PhilipsRC21191  
PhilipsRC2143  
PhilipsSF10  
Phonola313010821191  
Phonola313010821341  
Procyon313010821191  
Procyon313010821341  
PYE313010821191  
PYE313010821341  
Radiola313010821191  
Radiola313010821341  
Saville313010821191  
SBR313010821191  
SBR313010821341  
Schneider313010821191  
Sei313010821191  
Sei313010821341  
Siera313010821341  
Simatec313010821191  
Sinudyne313010821191  
Sinudyne313010821341

...

