

## Daljinski upravljač Sony

### RC-1627

RTV: P1627Y  
NJK: 1235  
MJK: 174  
PTK: P1627Y

Upotrebljiv za modele:

BAUR808.426  
BAUR808.436  
BAUR808.626  
BAUR808.636  
BAUR809.296  
BAUR809.306  
BAUR809.316  
BAUR809.326  
SONY  
2184WRTXT  
KV1403R  
KV1442AS  
KV1442EC  
KV1442ECPS  
KV1442ET  
KV1442FE  
KV1442UB  
KV1446TA  
KV1470R  
KV1554  
KV1554R  
KV16XMB  
KV16XMTA  
KV16XMTU  
KV1829M9  
KV19XMB  
KV19XMTA  
KV19XMTU  
KV19XMU  
KV1946R  
KV1954R  
KV1955R  
KV1957R  
KV1958R  
KV1967RWP  
KV1998R  
KV2010E  
KV2054  
KV21XMB  
KV21XMC  
KV21XMTA  
KV21XMTC  
KV21XMTU  
KV21XMU  
KV21XSD  
KV21XSTA  
KV211XMTU  
KV211XMU  
KV2132  
KV25XSTA  
KV25XTA  
KV2511A  
KV27VX1P  
KV2721D  
KV416



KVC25B  
KVC25TA  
KVC25TE  
KVC25TS  
KVC27B  
KVC27TA  
KVC27TDAAS  
KVC27TDAS  
KVC2721D  
KVC2910B  
KVC2911A  
KVC2933  
KVD3413E  
KVDX21B  
KVDX21TA  
KVDX21TD  
KVDX21TDTU  
KVDX21TE  
KVDX21TU  
KVDX2112  
KVDX27B  
KVDX27TA  
KVDX27TE  
KVDX27TU  
KVDX271TU  
KVE2511  
KVFX29TA  
KVFX29TD  
KVFX2913E  
KVH1610A  
KVH1610D  
KVM14A  
KVM14B  
KVM14E  
KVM14P  
KVM14TU  
KVM14U  
KVM16A  
KVM16B  
KVM16E  
KVM16TE  
KVM19A  
KVM19B  
KVM19TU  
KVM21TE  
KVM21TL  
KVM21TU  
KVM21U  
KVM2120B  
KVM2121  
KVM2130  
KVM2131D  
KVM2510B  
KVM2511A  
KVM2511E  
KVM2521A  
KVM2531A  
KVX21B  
KVX21TA  
KVX21TU  
KVX21XRTD  
KVX2120B  
KVX2121A  
KVX2129U  
KVX25TD  
KVX25TN  
KVX25TU  
KVX25XMTU  
KVX2520B  
KVX2521A

KVX2521D  
KVX2521E  
KVX2521M  
KVX2521U  
KVX2525A  
KVX2529U  
PVM2130QM  
PVM2730QM

...

Kompatibilan sa originalnim oznakama DU:

DARWIND1627  
MOTIP1627Y  
PILOTP1626Y  
PILOTP1627Y  
PILOTP1628Y  
PILOTP1629Y  
PILOTP1635Y  
BAURRM658  
BAURRM673(TV)  
SONY  
146548711  
A1465487A  
A1470708A  
A1470735A  
A1470738A  
A1470740A  
A1470742A  
A1470745A  
A1470747A  
A1470760A  
A1470779A  
A1470791A  
A1470801A  
A1470806A(TV)  
A1470811A  
A1470816A  
A1470818A(TV)  
A1470839A  
A1470840A  
A1470858A(TV)  
A1470866A  
A1470875A  
A1470876A(TV)  
A1470886A  
RM(VIDEO8)  
RM640(TV)  
RM650  
RM651  
RM652  
RM654  
RM655(TV)  
RM658  
RM665(TV)  
RM669(TV)  
RM670(TV)  
RM671(TV)  
RM672(TV)  
RM673(TV)  
RM674(TV)  
RM703  
RM712

...