

## Daljinski upravljač Samsung

### BN59-00941A

Za robnu marku:  
SAMSUNG

RTV: BN5900941A  
NJK: 1927  
MJK: 1927  
PTK:

Upotrebljiv za modele:

LE19B450C4W  
LE19B450H  
LE19B451C4H  
LE19B541C4WXXC  
LE19B650T6W  
LE19C450E1W  
LE19C451E2W  
LE22B450C4H  
LE22B450C4W  
LE22B450C8W  
LE22B451C4H  
LE22B457C6H  
LE22B470C  
LE22B541C4F  
LE22B541C4WXXC  
LE22B650T6WXXC  
LE22C350D1W  
LE22C450D1W  
LE22C452C4H  
LE22C453C4H  
LE22C457C6H  
LE26B350F1WXXC  
LE26B450C4H  
LE26B450C4W  
LE26B457C6H  
LE26B460B2WXXC  
LE26B470C  
LE32B350F1WXB  
LE32B350F1WXXC  
LE32B350F1WXXH  
LE32B350F1WXXN  
LE32B350F1WXXU  
LE32B350F1WXZG  
LE32B450C4H  
LE32B450C4WXXC  
LE32B451C4H  
LE32B457C6H  
LE32B460B2WXXC  
LE32B470C  
LE32B530P7WXXC  
LE32B541P7WXXC  
LE32B550A5WXXC  
LE32B550M2H  
LE32B551  
LE32B554M2WXXC  
LE32B570A5F  
LE32B650T2P  
LE32B650T2W  
LE32B651T3W  
LE32B652T4P  
LE32B652T4W  
LE32B653T5WXXC



LE32B672T4S  
LE32B952T4WXXC  
LE32C350D1W  
LE32C450E1W  
LE32C452C4H  
LE32C453C4H  
LE32C457C6H  
LE32C530F1W  
LE32C550J1W  
LE32C630K1P  
LE32C650L1P  
LE32C670M1Q  
LE37B457C6H  
LE37B530P7WXXC  
LE37B550A5P  
LE37B550A5WXXC  
LE37B550M2H  
LE37B551A6W  
LE37B554M2WXXC  
LE37B570A5F  
LE37B650T2P  
LE37B650T2WXXC  
LE37B651T3W  
LE37B652T4WXXC  
LE37B672T4S  
LE37C457C6H  
LE37C530F1W  
LE37C550J1W  
LE37C630K1P  
LE37C650L1P  
LE37C670M1Q  
LE40B450  
LE40B470C  
LE40B530P7W  
LE40B541P7W  
LE40B550A5P  
LE40B550A5W  
LE40B550M2H  
LE40B551  
LE40B554M2P  
LE40B554M2W  
LE40B570A5F  
LE40B620R3P  
LE40B620R3W  
LE40B650T2P  
LE40B650T2W  
LE40B651  
LE40B652T4P  
LE40B652T4W  
LE40B653T5W  
LE40B750U1W  
LE40C457C6H  
LE40C530F1W  
LE40C550J1W  
LE40C630K1P  
LE40C650  
LE40C650L1P  
LE40C652  
LE40C653  
LE40C670M1Q  
LE46B470C  
LE46B530P7W  
LE46B550A5P  
LE46B550A5W  
LE46B550M2H  
LE46B551  
LE46B554M2W  
LE46B620R3P  
LE46B620R3W  
LE46B650T2P

LE46B650T2W  
LE46B651T3W  
LE46B652T4W  
LE46B653T5W  
LE46B750U1PXXC  
LE46B750U1PXXN  
LE46B750U1PXZG  
LE46C550J1W  
LE46C630K1P  
LE46C650L1P  
LE46C652  
LE46C653  
LE46C654  
LE52C470C  
LE52B620R3P  
LE52B620R3W  
LE52B651  
LE52B750U1W  
LE55B650  
LE55B651  
LE55B652  
LN19C630  
LN19C6300  
LN19C640  
LN19C6400  
LN19C650  
LN19C6500  
LN22A330  
LN22A330J1D  
LN22A330J1DXZA  
LN22A650A1D  
LN22A650A1DXZA  
LN22C630  
LN22C6300  
LN22C640  
LN22C6400  
LN22C650  
LN22C6500  
LN26A330  
LN26A330J1  
LN26C630  
LN26C6300  
LN26C640  
LN26C6400  
LN26C650  
LN26C6500  
LN32A330  
LN32A330J1D  
LN32A330J1DXZA  
LN32A330J1DXZC  
LN32A330J1DXZX  
LN32A330J1N  
LN32A330J1NXZA  
LN32A330J1XRL  
LN32A330J1XSR  
LN32A330J1XZB  
LN32A330J1XZD  
LN32A330J1XZL  
LN32A330J1XZP  
LN32A650  
LN32A650A1FXZA  
LN32C630  
LN32C6300  
LN32C640  
LN32C6400  
LN32C650  
LN32C6500  
LN40A330  
LN40A330J1  
LN40A330J1D

LN40A330J1DXZA  
LN40A330J1DXZC  
LN40A330J1DXZX  
LN40A330J1XRL  
LN40A330J1XSR  
LN40A330J1XZL  
LN40A330J1XZP  
LN40C630  
LN40C6300  
LN40C640  
LN40C6400  
LN40C650  
LN40C6500  
LN46C630  
LN46C6300  
LN46C640  
LN46C6400  
LN46C650  
LN46C6500  
LN52C630  
LN52C6300  
LN52C640  
LN52C6400  
LN52C650  
LN52C6500  
P2270  
P42FHD  
PN19C630  
PN19C6300  
PN19C640  
PN19C6400  
PN19C650  
PN19C6500  
PN22C630  
PN22C6300  
PN22C640  
PN22C6400  
PN22C650  
PN22C6500  
PN26C630  
PN26C6300  
PN26C640  
PN26C6400  
PN26C650  
PN26C6500  
PN32C630  
PN32C6300  
PN32C640  
PN32C6400  
PN32C650  
PN32C6500  
PN40C630  
PN40C6300  
PN40C640  
PN40C6400  
PN40C650  
PN40C6500  
PN46C630  
PN46C6300  
PN46C640  
PN46C6400  
PN46C650  
PN46C6500  
PN50A400  
PN52C630  
PN52C6300  
PN52C640  
PN52C6400  
PN52C650  
PN52C6500

PS42A410C1CRU  
PS42A410C1SRU  
PS42A410C1XBT  
PS42A410C1XRU  
PS42A410C1XSV  
PS42A410C1XUA  
PS42A410C1XUM  
PS42A410C1XXC  
PS42A410C1XXH  
PS42A410C3XRU  
PS42A410C3XUA  
PS42A411  
PS42A412C4XXC  
PS42A416C1CXXE  
PS42A416C1DXXC  
PS42A416C1DXXH  
PS42A416C1DXXU  
PS42A418C4DXXC  
PS42A426C1MXZF  
PS42A450P2XBT  
PS42A450P2XRU  
PS42A450P2XUA  
PS42A450P2XXC  
PS42A451P1XBT  
PS42A451P1XRU  
PS42A451P1XUA  
PS42A451P1XXC  
PS42A451P1XXH  
PS42A451P1XXU  
PS42A456P2CXXE  
PS42A456P2DXXC  
PS42A456P2DXXH  
PS42A456P2DXXU  
PS42A457P1CXXE  
PS42A457P1DXXC  
PS42A457P1DXXH  
PS42A457P1DXXU  
PS42A466P2MXZF  
PS42A466P2WXXE  
PS42A467P1MXZF  
PS42A467P1WXXE  
PS42B430P2WXXC  
PS42B450B1W  
PS42B451B2W  
PS42C430  
PS42C430A1W  
PS42C45  
PS42C450B1W  
PS50A410C1XBT  
PS50A410C1XRU  
PS50A410C1XSV  
PS50A410C1XUA  
PS50A410C1XUM  
PS50A410C1XXC  
PS50A410C1XXH  
PS50A410C3XRU  
PS50A416C1CXEE  
PS50A416C1DXXC  
PS50A416C1DXXH  
PS50A416C1DXXU  
PS50A417C2DXXC  
PS50A418C4DXXC  
PS50A426C1MXZF  
PS50A450P2XBT  
PS50A450P2XRU  
PS50A450P2XUA  
PS50A450P2XXC  
PS50A450P2XXH  
PS50A451P1XBT  
PS50A451P1XRU

PS50A451P1XUA  
PS50A451P1XXC  
PS50A451P1XXH  
PS50A451P1XXU  
PS50A456P2CXXE  
PS50A456P2DXXC  
PS50A456P2DXXH  
PS50A456P2DXXU  
PS50A457P1CXXE  
PS50A457P1DXXC  
PS50A457P1DXXH  
PS50A457P1DXXU  
PS50A466P2MXZF  
PS50A466P2WXXE  
PS50A467P1MXZF  
PS50A467P1WXXE  
PS50A470P1  
PS50A476P1D  
PS50A550S2RXXC  
PS50A550S2RXXH  
PS50A551S3RXXC  
PS50A551S3RXXH  
PS50A552S1RXUA  
PS50A552S1RXXC  
PS50A552S1RXXH  
PS50A552S1RXXU  
PS50A556S2CXXE  
PS50A556S2FXXC  
PS50A556S2FXXH  
PS50A556S2FXXU  
PS50A557S3CXXE  
PS50A557S3FXXC  
PS50A557S3FXXH  
PS50A557S3FXXU  
PS50A558S1CXXE  
PS50A558S1FXBT  
PS50A558S1FXRU  
PS50A558S1FXXC  
PS50A558S1FXXH  
PS50A558S1FXXU  
PS50A566S2MXZF  
PS50A566S2WXXE  
PS50A567S3MXXE  
PS50A567S3MXZF  
PS50A568S1WXXE  
PS50A656T1F  
PS50A676  
PS50A756T1MXBT  
PS50A756T1MXRU  
PS50A756T1MXUA  
PS50A756T1MXXC  
PS50A756T1MXXH  
PS50A756T1MXXQ  
PS50A756T1MXXU  
PS50A766T1WXXE  
PS50B430P2W  
PS50B450B1W  
PS50B451B2W  
PS50B530S2W  
PS50B550T4P  
PS50B550T4W  
PS50B551T3W  
PS50B560T7W  
PS50B570T6S  
PS50B650S1P  
PS50B650S1W  
PS50B670S1S  
PS50B850Y1P  
PS50B850Y1W  
PS50C430

PS50C430A1W  
PS50C450B1W  
PS50C530C1W  
PS50C550G1W  
PS50C550G2W  
PS58A656T1F  
PS58A676  
PS58B680T6P  
PS58B680T6W  
PS58B850Y1P  
PS58B850Y1W  
PS63A676  
PS63A756T1MXBT  
PS63A756T1MXUA  
PS63A756T1MXXC  
PS63A756T1MXXH  
PS63A756T1MXXQ  
PS63A756T1MXXU  
PS63A766T1WXXE  
PS63B680T6P  
PS63B680T6W  
TVLED3D40"46"55"  
UE19C6500  
UE22C6500  
UE26C6500  
UE26C8000LED3D  
UE32B6000VW  
UE32B7000VP  
UE32C8000LED3D  
UE37B6000VP  
UE37B6000VW  
UE40B6000VW  
UE40B7000WWXXC  
UE40B7090WWXXC  
UE40B8000XW  
UE40C7000WP  
UE40C8000WP  
UE46B6000VW  
UE46B7000VW  
UE46B7000WW  
UE46B7020WPXXN  
UE46B8000XP  
UE46C7000WP  
UE46C8000WP  
UE52C8000LED3D  
UE55B7000WW  
UE55B7020WP  
UE55C6500UP  
UE55C7000WP  
UE55C8000WP  
UN19C630  
UN19C6300  
UN19C640  
UN19C6400  
UN19C650  
UN19C6500  
UN22C630  
UN22C6300  
UN22C640  
UN22C6400  
UN22C650  
UN22C6500  
UN26C6400  
UN26C630  
UN26C6300  
UN26C640  
UN26C650  
UN26C6500  
UN32C630  
UN32C6300

UN32C640  
UN32C6400  
UN32C650  
UN32C6500  
UN40C630  
UN40C6300  
UN40C640  
UN40C6400  
UN40C650  
UN40C6500  
UN46C630  
UN46C6300  
UN46C640  
UN46C6400  
UN46C650  
UN46C6500  
UN52C630  
UN52C6300  
UN52C640  
UN52C6400  
UN52C650  
UN52C6500  
UN55B7000  
UN55B8000  
UN55C6500  
...

Kompatibilan sa originalnim oznakama DU:

BN5900676A  
BN59006763A  
BN5900678A  
BN5900678B  
BN5900681A  
BN5900685A  
BN5900685B  
BN5900686A  
BN5900687A  
BN5900690A  
BN5900691A  
BN5900695A  
BN5900700A  
BN5900702A  
BN5900705B  
BN5900721A  
BN5900752A  
BN5900802A  
BN5900849A  
BN5900850A  
BN5900851A  
BN5900852A  
BN5900853A  
BN5900854A  
BN5900855A  
BN5900856A  
BN5900857A  
BN5900859A  
BN5900860A  
BN5900861A  
BN5900863A  
BN5900864A  
BN5900865A  
BN5900885A  
BN5900886A  
BN5900899A  
BN5900901A  
BN5900910A  
BN5900936A  
BN5900937A  
BN5900940A



BN5900941A  
BN5900942A  
BN5900943A  
BN5901039A  
BN5901052A  
BN5901054A  
BN6802388A