

Key Point for Motion Setting

Setting -> Alarm -> Video Motion

Channel Please set each channel, not only the channel 1.

Enable ☒ Make sure each channel status is Enabled

Sensitivity Region Check the region area

Period Interval Sec

Record Channel

Tour

PTZ Activation Delay Sec

☒ Show Message ☐ Send Email

☒ Buzzer Check response action ☐ FTP