

KA SLEDEĆIM DISTRIBUTERIMA

TASTER ZVONA



on



1 2 3 4 5 6



MONITOR 2

TASTER ZVONA



on



1 2 3 4 5 6



MONITOR 1


TASTER ZVONA



on



1 2 3 4 5 6



MONITOR 3

TASTER ZVONA



on




1 2 3 4 5 6




MONITOR 4

POTREBNO JE PRIDRŽAVATI SE
PREPORUČENE INSTALACIJE




DISTRIBUTER

PREKIDAČ IMPEDANSE
PREBACITI U "OFF"
OSIM NA POSLEDNJEM
DISTRIBUTERU




NAPAJANJE




230V ~

CRVENA
CRNA




RELEJ



EL. PRIHVATNIK

TASTER ZA IZLAZ



NAPAJANJE ZA EL. PRIHVATNIK